energilz

HYDROGEN WATER BOTTLE

QUICK START GUIDE



PREMIUM HYDROGEN HYDRATION

- H_2 HYDROGEN RICH WATER
- SPE/PEM TECHNOLOGY
- USB-C RECHARGEABLE
- 3 3-MINUTE CYCLE

1 BEFORE FIRST USE

I CHARGE THE BOTTLE

Fully charge the bottle before first use.

3-4 HOURS



II FILL WITH WATER & WAIT 30 MIN

Fill the bottle with clean drinking water and let it sit for 30 minutes.

30 MIN

III CLEANING MODE (5 MINUTES)

Press and hold the power button for 3 seconds to activate cleaning mode. This removes scale and prepares the bottle.

x2



IV REPLACE & REFILL WITH FRESH WATER

Once cleaning is complete, empty the bottle and refill it with fresh, clean drinking water.

V START HYDROGEN GENERATION (3 minutes)

Short press the power button once to start the 3 minute hydrogen generation cycle.

2 sec



2 DAILY USE



Best results: Drink within 30 minutes for maximum hydrogen concentration.

3 LED LIGHT GUIDE



CHANGING RAINBOW LIGHT

Hydrogen generation in progress.
3-minute cycle.



SOLID RED LIGHT

Charging or Cleaning mode.
Light turns off when complete.



FLASHING RED LIGHT

Battery is low.
Please recharge.

Thank You for Your Order

Validate Your Warranty Now!

In order to take advantage of the 3-year manufacturer defect warranty, please register at:

energilz.com/registration/

At Energilz we care about your satisfaction and stand behind our products! We want you to enjoy using them for as long as possible, and once the product is registered, you can be sure we will take care of it in case anything goes wrong.

energilz.com

4 CLEANING YOUR BOTTLE

AUTOMATIC CLEANING
(Scale Removal)



Fill bottle with water. | Press and hold the power button for 3 seconds | 5-minute cleaning cycle. | Done!

MANUAL CLEANING
(Glass Base Cleaning)



1. Open bottom cap. Turn the bottom cap clockwise
2. Wash glass with mild soap.
3. Wipe base
4. Check gasket is in place and close tightly.

5 SAFETY & CARE



If the bottle beeps 3 times and stops, the water quality is not suitable for hydrogen generation. Please replace it with fresh drinking water and try again.

6 TROUBLESHOOTING GUIDE

Problem	Solution
Water leaking? 	• Make sure the bottle is securely closed. • Open the bottom cap (turn clockwise) • Check that the silicone gasket is properly seated • Tighten the bottom cap firmly
No bubbles? 	• Mineral scale may have built up on the electrodes. • Run the Cleaning Mode twice. • If the problem persists, fill the bottom with a mixture of warm water and white vinegar at a 3:1 ratio (3 parts water to 1 part vinegar) and let it sit for 30 minutes. Then run the Cleaning Mode again.
Bottle won't charge? 	• Keep the USB-C charging port clean and dry. • Try another USB-C cable. • Try another USB charger.

SETUP VIDEO

Troubleshooting video

7 WARRANTY INFORMATION

The Energilz Hydrogen Water Bottle is covered by a three-year limited warranty from the date of purchase against defects in materials and workmanship under normal use. If your product develops a defect or you need assistance, please contact our customer support team.

This warranty does not cover damage caused by misuse, unauthorized repair modifications, or failure to follow the instructions in this manual. Scan the QR code below to register your warranty.

For assistance, contact:
support@energilz.com